

Features and Specifications Golf R-Line Golf Life Safety and Security <u>영</u> S S S Driver and front passenger airbags S S S Driver and front passenger side airbags Airbags S S S Rear seat side airbags S S S Curtain airbags, front and rear S S S Anti-theft Electronic engine immobiliser Fully galvanised body with 12 year corrosion perforation warranty S S S Body S S S Door side impact protection S S S Rigid safety cell with front and rear crumple zones Automatic flashing brake lights activated in emergency braking situation S S S S S S Anti-lock Braking System (ABS) S Auto hold function Manual model S S S Brake Assist **Brakes** S S S Electronic Brake-pressure Distribution (EBD) S S S Electro-mechanical parking brake S S S Hill Start Assist (HSA) Automatic models S S S Multi-collision brake S S Child seat top tether anchorage points (3) S Child restraints S S S ISOFIX child seat anchorage points, outer rear seats S S Front safety optimised head restraints, height adjustable -Head restraints Integrated front head restraints S S S S Rear head restraints height adjustable (3) Adaptive Cruise Control (ACC) with stop and go function* S S S S S S Automatic kerb function when reversing, passenger's side exterior mirror tilt Side Assist with Rear Traffic Alert S S S S S S Distance warning display S S S **Driver Fatigue Detection system** S S **Emergency Assist** S S Exit Warning System S S Front Assist with Pedestrian and Cyclist Monitoring functions S S S S Lane Assist **IQ.DRIVE** S Light Assist, automatic high beam headlight function S S S Manoeuvre braking, low speed emergency braking front and rear S S S Oncoming vehicle braking when turning S S S Optical Parking System (OPS) in infotainment display S S S Park Assist, parking bay and parallel parking assistance Parking distance sensors, front and rear with acoustic and visual warning S S S S S S Rear View Camera (RVC) with dynamic and static guidance lines S S S Traffic Jam Assist* S S S **Travel Assist** *Traffic Jam Assist and stop and go function automatic transmission models only S S S Child safety locks on rear doors S S Fuel filler flap lock/unlock by remote, push to open S S S Keyless Access, keyless entry and starting system including starter button Locking Keyless Go, keyless starting system including starter button S One touch lock / unlock for driver S S S Programmable locking functions S S S Remote central locking S S



Features and Spec	cifications			
Safety and Securit	y (Cont'd)	Golf	Golf Life	Golf R-Line
	Front height adjustable with pre-tensioners and belt force limiters Proactive occupant protection system in combination with Front Assist and Side Assist	S S	S S	S S
Seat belts	Outer rear with belt tensioner and force limiter Visual and acoustic warning for front and rear seat passengers seat belts not fastened	S S	S S	S S
	3 point seat belts for all passengers	S	S	S
Traction Control	Anti-Slip Regulation (ASR) Electronic Differential Lock (EDL) Electronic Stabilisation Program (ESP) Extended Electronic Differential Lock (XDL)	\$ \$ \$ \$	\$ \$ \$ \$	\$ \$ \$ \$
Exterior Equipmer	nt / Styling			
	Body coloured bumper bars and door handles Body coloured exterior rear view mirrors	S S	S S	S S
Exterior highlights	Lower body side sill extensions in gloss black Radiator grille highlights in gloss black and chrome Rear bumper with black diffuser	- S S	s S	S S
zmener mgmgme	R-Line front bumper with gloss black C signature, front spoiler and large lower air intake	-	-	S
	R-Line rear bumper with gloss black sports diffuser and chrome trim Trapezoidal chrome bumper trims, left and right	-	-	S S
	Coming / leaving home function	S	S	S
	Fog lamp, rear	S	S	S
	Illuminated door handle recesses LED headlights for low and high beam with LED daytime driving lights	S	S S	S
Exterior lighting	LED performance headlights for low and high beam with unique LED daytime driving light signature and automatic self-leveling	-	-	S
	LED rear tail lights	S	S	S
	Low light sensor with automatic headlight function	S	S	S
	Poor weather light and cornering light Rear registration plate light, LED	S	S	S
	Surround lighting with welcome light (projection from door mirror)	-	S	S S
	Gloss paint finish	S	S	S
Doint	Metallic / Pearl Effect paint finish	0	0	0
Paint	Premium Gloss paint finish	-	-	0
	Premium Metallic paint finish	0	0	0
T' - (1 - 1	Heat insulating tinted glass	S	S	S
Tinted glass	Dark tinted rear side window and rear window glass, 65% light absorbing Tinted rear tail light clusters	S	S	S S
	Alloy wheels (Norfolk) 16x7" with 205/55 R16 tyres	S	-	-
	Alloy wheels (Ventura) 17x7½" with 225/45 R17 tyres	-	S	-
Wheels	Alloy wheels (Bergamo) 18x7½" with 225/40 R18 tyres	-	-	S
	Anti-theft wheel bolts	S S	S S	S
	Low tyre pressure indicator Weight and space saving spare wheel	S	S	S S
Comfort and Conv				
Armrest	Front centre armrest, height and longitudinally adjustable with storage box and rear air outlets (2)	S	S	S
7 11111001	Rear seat centre armrest with cup holders (2) and load through provision	-	S	S



Features and Spec	ifications			
Comfort and Conv	enience (cont'd)	Golf	Golf Life	ω Golf R-Line
	3 zone automatic climate control air conditioning with Smart and Classic	S	S	S
	Climate menus			
Air conditioning	Air Care air cleaning function	_	_	_
3	Air quality and humidity sensor with automatic air recirculation	S	S	S
	Dust and pollen filter Touch slider temperature controls	S	S S	S
Comfort indicator fu	nction (1 x touch = 3 x flash)	S	S	S S
Common marcator ra	Front (2)	S	S	S
Cup holder	Rear (2)	-	S	S
•	Bottle holders in front door pockets	S	S	S
Driving profile select	tion - Eco, Comfort, Sport and Individual driving modes	-	-	S
Floor mats	Front and rear, carpet	-	S	S
Grab handles	Soft fold away grab handles, front and rear	S	S	S
	Digital Cockpit	S	-	-
	Colour digital display with customisable views of speedometer, tachometer,			
	driving data and driver assistance systems Composition Media audio system	S		
	8.25" colour capacitive touch screen display with smartphone style HMI, AM/FM	3	-	-
	radio, telephone, media, App-Connect, sound, vehicle and driver assistance			
	system settings			
	Innovision Cockpit			
	Digital Cockpit Pro	-	S	S
	Colour digital display with multiple customisable views of speedometer,			
	tachometer, navigation, driving data, audio, telephone and driver assistance			
	systems Discover Pro audio and satellite navigation system	_	S	S
	10.0" colour capacitive touch screen display with smartphone style HMI,		Ü	J
	customisable home screen, proximity sensor, gesture and voice control,			
In car entertainment	AWA W radio, havigation map views, telephone, media, App-Connect, Sound,			
and technology	background lighting, vehicle and driver assistance system settings			
	App-Connect USB interfaces for Apple CarPlay [®] and Android Auto [™] in front	S	S	S
	centre console		_	_
	Wireless App-Connect for Apple CarPlay® and Android Auto™	-	S S	S S
	Inductive wireless charging 2 USB-C ports in the front, 2 USB-C charging sockets on the centre console	S	S	S
	in the rear	Ü	Ü	Ŭ
	Audio, voice control, driver assistance system and Digital Cockpit control	S	S	-
	buttons mounted on steering wheel			
	Audio, voice control, driver assistance system and Digital Cockpit touch	-	-	S
	controls mounted on sports steering wheel	_	_	_
	Bluetooth® phone connectivity with contacts display, operation via touch	S	S	S
	screen infotainment system or Digital Cockpit and Bluetooth® audio streaming	C		
	Speakers, front and rear (6) Speakers, front and rear (6) plus centre speaker	S	S	S
	Aluminium finish accelerator and brake pedals		-	S
	Chrome highlight trim on air vents, power window and exterior mirror switches	-	S	S
Interior highlights	Decorative inlays, "new look" to dashboard and front doors	S	-	-
	Decorative inlays, "nature crossed brushed" to dashboard and front doors	-	S	-
	Decorative inlays, "carbon grey" to dashboard and front doors	-	-	S
	With time delay	S	S	S
Interior lighting	LED front reading lights (2) and rear passenger reading lights (2) 10 colour LED ambient lighting	S	S S	S
ii itorioi ligi itilig	9 9	_		_
3 3	30 colour LED ambient lighting	-	Р	S



Features and Specifications

reatures and Spe	ecinications			
Comfort and Con	venience (cont'd)	Golf	Golf Life	Golf R-Line
	Load restraining hooks	S	S	S S
	Luggage compartment light	S	S	S
Luggage	Luggage cover, removable	S	S	S
compartment	Shopping bag hooks	S	S	S
compartment	Storage compartments in side lining	S	S	S
	Variable luggage compartment floor level	S	S	S
	12 volt socket	-	S	S
	Automatic dimming interior rear-view mirror	S	S	S
Mirrors	Electrically heated and adjustable exterior mirrors	S	S	S
WIIITOTS	Electrically foldable exterior mirrors	-	S	S
	LED turn indicators integrated in exterior mirrors	S	S	S
Power steering	Electro-mechanical, vehicle speed and steering input sensitive	S	S	S
	Standard front seats	S	-	-
	Comfort front seats	-	S	-
	Sport front seats	-	-	S
Seating	Height adjustment for front seats	S	S	S
	Lumbar adjustment for front seats, manually adjustable	-	S	S
	Split folding rear seat backrest (40/60)	S	S	S
	Rear seat centre armrest with cup holders (2) and load through provision	-	S	S
	3 spoke leather covered steering wheel	S	S	S
	3 spoke leather covered flat bottomed sports steering wheel	-	-	S
Steering wheel	Audio, driver assistance and Digital Cockpit controls	S	S	S
	Gearshift paddles Automatic models	S	S	S S
	Height and reach adjustable steering wheel	S	S	S
	Centre console storage compartment under armrest	S	S	S
	Compartment in dashboard centre console	S	S	S
	Glove compartment with illumination	S	S	S
Storage	Front door pockets with bottle holders, lined	S	S	S
	Front seat backrest storage pockets	-	S	S
	Net on front passenger side centre console	S	S	S
	Rear door pockets, lined	S	S	S
Sunroof	Panoramic glass sunroof, electrically slide and tilt adjustable with integrated wind deflector and sunblind	-	Р	0
	6 speed manual transmission	S	-	-
Transmission	8 speed automatic transmission with sport mode	Ö	S	S
	Cloth seats	S		-
Upholstery	Comfort cloth seats	_	S	_
Ophiololory	Sport cloth and microfleece seats	_	-	S
	Driver's and passenger's side vanity mirrors in sun visor	S	S	S
Vanity mirrors	Illuminated on driver's and passenger's side	S	S	S
Windows	Power front and rear, with roll-back function and one-touch up-down	S	S	S
	Remote operated convenience close and open feature (programmable)	S	S	S
	2 speed aero windscreen wipers with wash/wipe	S	S	S
Winers	Rain sensor	S	S	S
Wipers		S	S	S
	Rear window with wash/wipe and intermittent wipe Centre console	S	S	S
12V socket		3		
	Luggage compartment	-	S	S



Features and Specifications ○ Golf R-Line **Optional Packages** Harman Kardon 480W premium audio system with 8 speakers plus subwoofer Sound & Vision and 12-channel amplifier Head up display, windscreen projection - display of speed, driver assistance package systems and navigation turn by turn direction 30 colour LED ambient lighting including front passenger foot wells 0 Comfort sport front seats Comfort & Style Microfleece and cloth seat upholstery package Panoramic glass sunroof, electrically slide and tilt adjustable with integrated wind deflector and sunblind



Colour Combinations

EXTERIOR COLOUR							
	Pure White	Moonstone Grey P	Reflex Silver M	Dolphin Grey M	Atlantic Blue M	Pomelo Yellow PM	Deep Black PE
INTERIOR TRIM							
Golf							
Black cloth seat upholstery	S	-	S	S	S	S	S
Golf Life							
Black comfort cloth seat upholstery	S	-	S	S	S	S	S
Black comfort sport microfleece and cloth seat upholstery	0	-	0	0	0	0	0
Golf R-Line							
Black sport cloth and microfleece seat upholstery	S	S	-	S	S	S	S

Please note: Premium (P), Metallic (M), Premium Metallic (PM) and Pearl Effect (PE) paint are optional at additional cost.



En ada a		litura TOI
Engine		litre TSI
Туре		ection petrol with engine Start/Stop system*
Installation		transverse
Cubic capacity, litres/cc		4/1395
Bore/stoke, mm		.5/80.0
Max power, kW @ rpm		@ 5000
Max torque, Nm @ rpm		1500 - 4000
Compression ratio	1	10.5:1
Ignition system	Ele	ectronic
Exhaust emission control	Exhaust gas recirculation, three way	y catalytic converter and lambda probes
Fuel type (Recommended)	Premium unlead	ed 95 RON minimum
Transmission	6 Speed Manual [^]	8 Speed Automatic
Driven wheels	Front wheel drive	Front wheel drive
Performance		
0 – 100 km/h, seconds	8.3	8.5
Fuel Consumption **		
Combined, L/100km	6.0	5.8
Urban, L/100km	7.6	7.2
Extra Urban, L/100km	5.0	5.0
CO2 emission g/km~	136	132
Fuel tank capacity litres	50	50
Suspension		
Front Axle	Independent, MacPherson struts with lower	A-arms. Anti-roll bar. Sports suspension R-Line.
Rear Axle	Independent, four-link with coil spring	s. Anti-roll bar. Sports suspension R-Line.
Steering		
Steering systems	Electro-mechanical power assisted rack 8	& pinion steering. Progressive steering R-Line.
Turning Circle (m)		10.9
Brakes		
Front	Ventil	lated discs
Rear		Discs
Brake Systems		ic Brake-pressure Distribution (EBD), Brake Assist am (ESP). Brake energy recuperation.



Technical Specifications (cont'd)

Weights	6 Speed Manual^	8 Speed Automatic
Tare Mass kg's	1270	1304
Towbar Capacity, braked~≠ kg	1500	1500
Towbar Capacity, unbraked~≠ kg	650	660
Towbar Load Limit~≠ kg	80	80
Exterior Dimensions		
Overall length mm	4	1284
Width mm	1	1789
Height mm	1	456
Wheelbase mm	2	2636
	Colf	Life
	Golf	R-Line
Track, front mm	1539	1533
Track, rear mm	1509	1503
Luggage Area Dimensions		
Volume, rear seat upright L		374
Volume, rear seat folded L	1	1230
Length, rear seat upright mm		800
Length, rear seat folded mm	1	1493
Width between wheel arches mm	1	1003

[^]The 6 Speed Manual transmission is only available with the Golf model grade.

[~] Emission level according to European Regulation (EC) No. 715/2007 and Regulation (EC) No. 692/2008

^{*}The Start/Stop system is designed to reduce fuel consumption and CO2 emissions. It achieves this by automatically switching off the engine while the vehicle is stationary and then starting it again automatically when the driver wants to drive off. There are certain operating conditions where the Start/Stop system is deactivated (e.g. during engine warm-up), please refer to the owner's manual for full operating information.

[~] Please note towbar capacities are applicable to the Genuine Volkswagen Accessory towbar.

[≠] Please note, Volkswagen Group Australia does not endorse or will not be held liable for any claim, loss or damage arising from the use or fitment of electronic trailer brakes.

^{**}Fuel consumption figures according to ADR 81/02 derived from laboratory testing. Factors including but not limited to driving style, road and traffic conditions, environmental influences, vehicle condition and accessories fitted, will in practice in the real world lead to figures which generally differ from those advertised. Advertised figures are meant for comparison amongst vehicles only.



Glossary

Adaptive Cruise Control (ACC)

Adaptive Cruise Control (ACC) is an extension of the conventional cruise control system with advanced capabilities based on a radar sensor. When ACC is activated, the vehicle automatically brakes and accelerates to a speed and distance set by the driver.

If the Golf approaches a slower vehicle, the ACC brakes the car to the same speed and maintains the pre-selected distance. Even when a vehicle pulls into the same lane in front of you or slows, your vehicle is automatically decelerated to the pre-selected distance. If the vehicle ahead moves out of your lane, the Golf then accelerates up to the pre-set desired speed.

Deceleration of the vehicle may take place via intervention in the engine management system. If deceleration via engine torque is not sufficient, brake intervention takes place, braking the vehicle to a standstill if the traffic situation necessitates in vehicles equipped with an automatic transmission. ACC can be reactivated automatically by depressing the accelerator pedal. In vehicles fitted with a manual transmission, the system is automatically deactivated at speeds below 30 km/h and the driver is prompted to take charge by visual and acoustic signals.

In the R-Line model grade, the dynamics of the ACC system can by individually varied by selecting one of the driving programs from the driving profile selection.

Adaptive Cruise Control (ACC) cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle and must monitor the speed and distance in relation to other vehicles. The ACC system should not be used on winding roads or in adverse weather conditions such as heavy rain.

Anti-lock Braking System (ABS)

When braking, wheel speed sensors measure the road wheel speed and should one or more wheels start to lock the ABS system reduces brake pressure to that wheel. This prevents the wheels from locking during heavy or emergency braking, enabling the vehicle to remain steerable.

Anti-Slip Regulation (ASR)

ASR is a traction control system that prevents the wheels from spinning under acceleration by reducing engine torque.

Auto Hold function^

As soon as the vehicle comes to a complete stop, the ABS hydraulic unit stores the vehicles final braking pressure. So even when you take your foot off the brake pedal, all four wheels brakes remain applied, providing increased comfort in stationary traffic. This function is released automatically when you drive off again.

Brake Assist

During emergency braking, Brake Assist aids the driver by increasing the brake pressure automatically to a level exceeding the locking limit. The ABS is thus quickly brought into the operating range, which enables maximum vehicle deceleration to be achieved.



Glossary

Driving Profile Selection^

Driving profile selection provides the driver with a wide-ranging choice of settings that can be made to the vehicle according to the driver's preferences. The driver has the option of choosing between the following driving profiles: Eco, Comfort, Sport and Individual. Eco mode has been designed to enhance fuel efficiency by adapting engine performance, earlier gearshift points and consumption-optimised control of the air conditioning system. The Comfort profile offers a comfortable but dynamic driving style. Sport provides faster response of the accelerator pedal and steering while the automatic switches to Sport mode. The Individual setting allows the driver to separately set various parameters including steering, engine, Adaptive Cruise Control (ACC) and air conditioning.

Electronic Brake-pressure Distribution (EBD)

Electronic, more sophisticated means of regulating the ratio of front/rear brake pressure. Settings are varied according to driving and load conditions to ensure each wheel is braked to the optimum extent.

Electronic Differential Lock (EDL)

EDL improves driving and steering characteristics when accelerating on road surfaces where each wheel has a different degree of traction. The system operates automatically and is combined with the ABS system. Using the ABS wheel sensors, EDL monitors the speed of the individual driving wheels. When a difference in driving wheel speed is detected (i.e. when one wheel starts to spin due to differences in road surfaces, e.g. due to water or dirt) the system brakes the spinning wheel, transferring engine power to the wheel with the best traction.

Electronic Stabilisation Program (ESP)

ABS and ASR traction control systems are integrated into the Electronic Stabilisation Program (ESP). In short, ESP helps ensure that the vehicle goes where you steer it even in extreme driving conditions. The ESP system constantly compares the actual movement of the vehicle with pre-determined values and should a situation arise where the vehicle starts to skid, ESP will apply the brakes to individual wheels and automatically adjust the engine's power output to correct the problem. ESP prevents the vehicle from losing control when trying to avoid an accident, for example. It also reduces the effects of understeer or oversteer.



Glossary

Emergency Assist^

Emergency Assist monitors the driving characteristics and recognises, within the limits of the system, if the driver suddenly becomes incapable of driving (due to the vehicle not being controlled).

Emergency Assist detects a lack of activity on the part of the driver and issues repeated visual and acoustic warnings and initiates a quick jolt of the brakes and tensioning of the driver's seatbelt to request the driver to take control of the vehicle.

If the driver remains inactive, the system automatically controls acceleration, braking and steering to slow the vehicle down and keep it in the lane. If there is sufficient stopping distance, the system decelerates the vehicle to a complete stop and switches on the electronic parking brake automatically, parking position is engaged, the doors are unlocked and the interior lighting switched on.

When Emergency Assist is actively controlling the vehicle, the hazard warning lights are switched on and the vehicle horn may sound to warn other road users. Ideally this will prevent a collision, or at least reduce its severity.

Emergency Assist cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle and must monitor the speed and distance in relation to other vehicles. Emergency Assist utilises both the Adaptive Cruise Control (ACC) and Lane Assist driver assistance systems. The ACC system should not be used on winding roads or in adverse weather conditions such as heavy rain. The system will not work if there are no recognisable lane markings. The camera vision can be reduced by rain, snow, heavy spray or oncoming lights. This and vehicles in front of you can lead to the lane markings not being recognised by the Lane Assist system.

Exit Warning System^

While the Golf is stationary, the exit warning system warns the occupants about a potential collision when a door is opened. The system uses the rear radar sensors to monitor the area behind and to the side of the vehicle. Where possible, it detects objects, such as cars and cyclists, as they approach the vehicle from behind. When you open the door, the warning lamp on the exterior mirror flashes if another road user in a critical situation is detected. At the same time an acoustic warning signal is heard. The corresponding warning lamps also flash if another road user is detected in a critical situation while the door is already open.

Exit warning system cannot replace the driver's attentiveness. If the driver or passenger notices a risk that pedestrians, other vehicles or objects could be damaged or if they are uncertain of the risk, they will need to react accordingly.

Extended Electronic Differential Lock (XDL)

XDL is an extension of the Electronic Differential Lock (EDL) function. When cornering, XDL responds to the load relief at the front wheel on the inside of a corner. The ESP hydraulics are used for the XDL to apply pressure to the wheel on the inside of the corner in order to prevent wheel spin. This improves traction and reduces the tendency to understeer. As a direct result of the one-sided and precise braking pressure, cornering is sportier and more accurate.



Glossary

Fatigue Detection

The driver Fatigue Detection system automatically analyses the driving characteristics and if they indicate possible fatigue, recommends that the driver takes a break. The system continually evaluates steering wheel movements along with other signals in the vehicle on motorways and others roads at speeds in excess of 60 km/h, and calculates a fatigue estimate. If fatigue is detected, the driver is warned by information in the Multi-function Display and an acoustic signal. The warning may be repeated once if the driver has not taken a break.

Fatigue Detection cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle and therefore determining whether or not they are fit to drive. The driving behaviour can be evaluated only when the speed is above approximately 60km/h. The functionality of the system is restricted given a sporty driving style, winding roads and poor road surfaces.

Front Assist with Pedestrian and Cyclist Monitoring functions

The Front Assist ambient traffic monitoring system uses a radar sensor and multi-function camera to detect critical distance situations and thus help to shorten the braking distance, reducing the risk of a rear-end collision.

If a vehicle is detected ahead of you in the lane, the distance and the speed relative to it are calculated. If the gap is closing too fast, Front Assist initially warns the driver by means of an audible as well as a visual signal. At the same time, the brake pads are brought into contact with the brake discs and the sensitivity of the Brake Assist is increased. This primes the braking system for a possible emergency stop. Furthermore, an automatic jolt of the brakes warns the driver of the danger. If the driver also fails to react to the warning jolt, Front Assist brakes automatically, helping to avoid a collision or reduce the severity of the accident.

At vehicle speeds below 30km/h, the system monitors the area ahead of the car for vehicles which might present a threat of collision. If a collision is likely, the brakes are first pre-charged and makes the Brake Assist system is made more sensitive: if the driver should notice the risk, the car is ready to respond more quickly to their braking action. However, if the driver still takes no action and a collision becomes imminent, emergency braking is independently applied. If the driver intervenes to try to avoid the accident, either by accelerating hard or by steering, the system will deactivate and allow the driver to complete the avoidance manoeuvre.

Pedestrian and Cyclist Monitoring is an extension of the Front Assist monitoring system. The system uses a radar sensor in the radiator grille and windscreen mounted multi-function camera to monitor the area in front of the vehicle and within the limits of the system, register certain situations, for example a pedestrian stepping onto the road suddenly. The system then gives an immediate acoustic and visual signal to warn the driver. If the driver does not brake, the system initiates a jolt of the brake as a warning about the critical situation, while at the same time preparing for hard braking. If the driver fails to react, the system automatically performs emergency braking, within system limits. Ideally this will prevent a collision, or at least reduce its severity.

Front Assist with Pedestrian and Cyclist Monitoring cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle and must monitor the speed and distance in relation to other vehicles.



Glossary

Lane Assist

Lane Assist is a lane departure warning system that is designed to help reduce the likelihood of the vehicle leaving the road or crossing into on oncoming lane and therefore the risk of accident as a result of driver distraction or a lapse in concentration.

The Lane Assist system monitors the road ahead with the aid of a camera (located near the interior rear-view mirror) which recognises lane markings and evaluates the position of the vehicle at speeds above 60km/h. If the vehicle starts to leave the lane, the Lane Assist system takes corrective steering action. If this is not sufficient the driver is warned about the situation by a steering vibration. Additionally, if no active steering movements by the driver are recognised, a message will appear in the Digital Cockpit in conjunction with a warning tone. The corrective steering function can be overridden by the driver at any time and the system does not react if the turn indicator is set before crossing a lane marking.

Lane Assist cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle and therefore staying in the lane at all times. The system will not work if there are no recognisable lane markings. The camera vision can be reduced by rain, snow, heavy spray or oncoming lights. This and vehicles in front of you can lead to the lane markings not being recognised by the Lane Assist system.

Light Assist^

Light Assist provides enhanced comfort and safety on the road by means of automatic high beam control. A camera on the interior mirror observes the traffic above 60 km/h and in complete darkness, Light Assist automatically switches on the high beam headlights. The system detects vehicles travelling ahead, as well as oncoming traffic and automatically dips the headlights before they are dazzled. Automatic alternation between high beam and low beam headlights ensures optimum illumination of the road ahead.

Manoeuvre braking

Manoeuvre braking assists the driver to avoid or reduce damage in a potential collision by initiating emergency braking. It supports the driver during forward and reverse manoeuvring in a speed range of a maximum 10 km/h. If the risk for an accident is recognised by the parking distance sensors, emergency braking is initiated to minimise possible damage.

Manoeuvre braking cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle. The object must be detected by the sensors. If the driver notices a risk that pedestrians, other vehicles or objects could be damaged they need to react accordingly and stop the vehicle.



Glossary

Multi-collision brake

The multi-collision brake has been designed to provide effective assistance for the driver in the moments after an accident. Multi-collision brake triggers automatic controlled braking once an initial collision has been detected so as to reduce the intensity of further accidents after a collision and can help prevent follow-on collisions with oncoming traffic.

The triggering of the multi-collision brake is based on a collision being detected by the airbag sensors. The ESP control unit limits the deceleration of the vehicle by the multi-collision brake to a defined value and vehicle speed. The vehicle can still be controlled by the driver, even when automatic braking is taking place. The driver can interrupt the multi-collision braking at any time by accelerating or braking even more strongly.

Oncoming vehicle braking when turning

Oncoming vehicle braking when turning aims to prevent or reduce the impact of head-on collisions with vehicles when turning. The front radar sensor and windscreen camera are used to monitor the area in front of the driver's own vehicle. If a hazardous situation is detected – the driver turns into oncoming traffic, the vehicle is automatically braked and a warning issued to help prevent a collision.

Key variables for detection of the turning manoeuvre are the steering angle and the steering-angle speed. A turning manoeuvre is detected even if the turn signal has not been activated. The function is active up to a speed of approximately 15 km/h.

Oncoming vehicle braking when turning cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle and must monitor the speed and distance in relation to other vehicles.

Park Assist

The third generation Park Assist system actively helps the driver when entering or reversing into 90° parking bays, as well as reversing into and driving out of parallel parking spaces. The system works by using sensors mounted either side of the front and rear bumpers together with parking distance sensors front and rear. To park, the driver simply presses the Park Assist button to select the type of parking manoeuvre and uses the appropriate indicator as the car slowly passes the potential parking space. Sensors scan the size of the parking space as the car is driven past and the driver is alerted if the parking space is big enough. If there is sufficient space, the driver stops the car, selects the correct gear and lets go of the steering wheel.

Park Assist will alert the driver of the intended path and subsequently the appearance of obstacles in the Multi-Function Display, within the driver's field of vision. Park Assist then actively supports the driver by taking over the steering control and parks the vehicle in the available space using the ideal course, if necessary with several moves. The driver can however take over the control of the steering at any time and end the automatic parking procedure.

Park Assist cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle. If the driver notices a risk that pedestrians, other vehicles or objects could be damaged or if they are uncertain of the risk, they will need to react accordingly and stop the vehicle, ending the function.



Glossary

Proactive occupant protection system

The proactive occupant protection system incorporates active and passive safety elements. When the system detects a potential accident situation at speeds above approximately 30km/h, the occupants and the vehicle are prepared for a possible accident. Automatic reversible tensioning of the seat belts secures the driver and front passenger in their seats to attain the best possible protective potential of the airbag and belt system. The hazard warning lights are activated. In case of high transverse dynamics the side windows (and optional panoramic sunroof) are also closed, leaving just a small air gap. Closing of the windows offers optimal support to the head and side airbags which results in the best possible protection.

The latest generation of the Proactive Occupant Protection System can detect risks at the rear utilising the signals from the rear radar sensors for the Side Assist system. If the system recognises an immediate risk, the vehicle and occupants are prepared for a possible rear end collision by warning an approaching vehicle with fast hazard warning light frequency, closing the side windows (and optional panoramic sunroof), as well as tighten the front seat belts.

Side Assist with Rear Traffic Alert

Side Assist with Rear Traffic Alert system supports the driver in assessing and avoiding dangerous situations, especially in critical situations, e.g. city and heavy traffic. Side Assist detects cars and motorcycles next to and up to 70m to the right and left behind your own vehicle and highlights these vehicles via a LED indicator in the door mirror at speeds above 15km/h. If you indicate to change lanes, the system calculates whether one of them could be dangerous due to position and speed and if deemed necessary will draw attention to this by flashing noticeably. In this instance, Lane Assist can also apply corrective steering to help avoid a collision.

Rear Traffic Alert monitors the traffic crossing behind the vehicle when reversing out of a parking space or manoeuvring. Utilising the Side Assist radar sensors in the rear bumper the system warns the driver of approaching traffic via an audible warning followed by a visual message in the Optical Parking System (OPS) and can also provide braking intervention if necessary to help avoid a collision.

Side Assist with Rear Traffic Alert cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle and must monitor the speed and distance in relation to other vehicles.

Traffic Jam Assist^

that is stopping.

In congested traffic situations, Traffic Jam Assist makes driving significantly more comfortable and helps to avoid typical rear-end collision accidents. The Traffic Jam Assist function combines the driver assistance systems Adaptive Cruise Control (ACC) and Lane Assist with adaptive lane guidance. In a speed range of 0-60km/h, the system automatically controls acceleration, braking, steering and if required, will decelerate to a stop behind a vehicle

Traffic Jam Assist cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle and must monitor the speed and distance in relation to other vehicles. Traffic Jam Assist has been developed for use only on motorways. The ACC system should not be used on winding roads or in adverse weather conditions such as heavy rain. The system will not work if there are no recognisable lane markings. The camera vision can be reduced by rain, snow, heavy spray or oncoming lights. This and vehicles in front of you can lead to the lane markings not being recognised by the Lane Assist system.



Glossary

Travel Assist

Travel Assist is an assistance system for partly automated driving. At the push of a button, Travel Assist can support the driver in monotonous and tiring driving situations commonly encountered on long motorway journeys. This system combines the functions of Adaptive Cruise Control (ACC), Lane Assist with adaptive lane guidance and Side Assist to accelerate, brake and maintain the vehicles position within its lane. The capacitive steering wheel can detect whether the driver's hands are on the steering wheel in readiness to steer the vehicle and will issue a visual and audible warning when not detected.

Travel Assist cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle and must monitor the speed and distance in relation to other vehicles. Travel Assist has been developed for use only on motorways. The ACC system should not be used on winding roads or in adverse weather conditions such as heavy rain. The system will not work if there are no recognisable lane markings. The camera vision can be reduced by rain, snow, heavy spray or oncoming lights. This and vehicles in front of you can lead to the lane markings not being recognised by the Lane Assist system.

Only available on selected models

Volkswagen is distributed by Volkswagen Group Australia Pty Ltd, 24 Muir Road Chullora, NSW 2190. ABN 14 093 117 876. Specifications are as planned at May 2021, for Model Year 2021 and are subject to change without notice or obligation. All information is this specification sheet is correct at the time of publication, however variations may occur from time to time and Volkswagen, in so far as it is permitted by law to do so, shall not be liable in any way as a result of any reliance by any person on anything contained in this specification sheet. Authorised Volkswagen dealers will provide up-to-date information on model application, design feature, prices and availability on request.

Apple CarPlay® and Apple Lightning® are registered trademarks of Apple Inc. Android Auto™ is a registered trademark of Google Inc. Bluetooth® is a registered trademark of Bluetooth SIG Inc.